

# 44 001 – AN – 12.1998


## AXLE ER 8 / ER 11 / AUSTERAS

AXLE	VEHICLE
ER 8	MAGNUM PREMIUM
ER 11	
AUSTERAS	

**NOTE**

The above information may change in the course of time.

Only the "Consult" section of the workshop manuals repertory in standard N° 10320 serves as reference.



**AXLE ER 8 / ER 11 / AUSTERAS****CONTENTS**

<b>VOLUMES</b>	<b>DESIGNATION</b>	<b>PAGES</b>
	Conventional symbols	2
<b>A</b>	Specifications	A1 → A7
<b>B</b>	Hubs	B1 → B5
<b>C</b>	Stub axle	C1 → C5
<b>D</b>	Tools	D1 → D2

**CONVENTIONAL SYMBOLS**

Tighten to torque (Nm) (right-hand thread)



Loosen by the indicated value



Heat or cool. Temperature in degrees Centigrade (e.g.: 80 ° C)



Weld bead



Repair time – Heating time



Smear (see “Consumables” table)



Grease or oil (see “Consumables” table)



Place in contact



Maximum out-of-true



... Greater than ...



Part to be replaced

## SPECIFICATIONS

**Axle type** ..... **ER 8 / ER 11**

**Symbol code**

Example

<b>E</b>	Axle
<b>R</b>	Lift-up
<b>8</b>	Load on axle in tonnes
<b>A</b>	Braking index

**Axle type** ..... **AUSTERAS**

Wheel alignment (toe-in) ..... **2.5 ± 1 mm/m**

Lockover angle (right) ..... **13°**

Lockover angle (left) ..... **13°**

**Consumables**

**Oil capacities and specifications** (See Servicing Handbook)

<b>Fastening, locking and sealing products</b>	
<b>Industrial reference</b>	<b>Automotive reference</b>
Loctite 270	LT 270 Strong thread-locking
Loctite 549	LT 549 Autoform

**Preparation prior to assembly**

Carefully clean and inspect all the parts.

Wash the bearings in clean solvent.

Let them drip dry naturally.

Immediately prior to assembly, lubricate them lightly with thin oil.

Do not unpack a new bearing until you are ready to install it.

Do not clean the the protective grease off new bearings.

Seals and lock-plates must always be discarded and new ones fitted.

Never force-fit parts with copper or brass punches or drifts.

Use a specially adapted plunger each time so as to prevent metallic particles getting into the casings and bearings.

Always oil parts prior to force fitting.

The inside of the lips of seal rings must be smeared with grease.

Shrink fitted parts must be heated with a hot air blower or in an oven, etc... Flame heating is strictly forbidden.

**NOTE**

When using a torque multiplier, calibrate the torque wrench-torque multiplier assembly to the desired torque.

**Locking, fastening, sealing and gluing products**

Prior to assembly, carefully clean the surface of the parts to which the product is to be applied. Get rid of any old product residue. Threaded portions are to be brushed, tapped and cleaned if necessary using a suitable cleaner.

**Using the product**

Always adapt the recommended product by following the directions for use appearing on the pack :

- surface finish,
- operating temperature,
- reaction, drying times, etc...,
- shelf-life.

Comply with the method of assembly so as to guarantee the quality of the repair.

### Tightening torques

There are several types of tightening

- Tightening to torque (in **Nm.**)
- Tightening to angle (in °)
- Tightening to torque–angle (in **Nm. + °**)

Torques given in **Nm** are nominal torques (average value calculated on the basis of the minimum torque and the maximum torque).


The tightening accuracy class defines the tolerance of this torque in percent as a function of the nominal torque applied.

### Tightening accuracy classes

- **Class I** : Special threaded hardware (tolerances variable depending on assembly)
- **Class II** : Reserved for precise tightening (tolerance  $\pm 10\%$  of the nominal torque)
- **Class III** : Reserved for normal standard tightening (tolerance  $\pm 20\%$  of the nominal torque)


For standard threaded hardware indicated in the table below, use tightening class **III**.


For other torques, see pages **A3** → **A6**.




21 0122

Tightening torques for conventional nut and bolt hardware to "METRIC system" standard 01.50.4002		
Dia. and pitch of nuts and bolts (in mm)	Quality class 8.8	Quality class 10.9
	Tightening class III ( $\pm 20\%$ )	Tightening class III ( $\pm 20\%$ )
6 x 1.00	7.4	10.8
7 x 1.00	12.1	17.8
8 x 1.00	19.2	28.2
8 x 1.25	17.9	26.3
10 x 1.00	39.4	58
10 x 1.25	37.4	55
10 x 1.50	35.4	52
12 x 1.25	67	98
12 x 1.50	64	94
12 x 1.75	61	90
14 x 1.50	105	155
14 x 2.00	98	143
16 x 1.50	161	237
16 x 2.00	151	222
18 x 1.50	235	346
18 x 2.50	210	308
20 x 1.50	328	481
20 x 2.50	296	435
22 x 1.50	444	652
22 x 2.50	406	596






44 0002A





44 0003A

AUSTERAS









44 0005A

$A < B$   
 $B = A + 2.5 \pm 1 \text{ mm/m}$   
 $a < b / a1 < b1$   
 $a = a1$   
 $b = a + 1.25 \pm 0.5 \text{ mm/m}$   
 $b = b1$   
 $(C = D) = 13^\circ$

**HUBS**



**ER 8 / ER 11****Removal**

On vehicle or on support.  
Remove the roadwheels.  
Drain the oil from the hub.

**Disassembly**

The item numbers indicated in the drawing on page **B2** correspond to the **sequence of disassembly**.


The table indicates the designation and the reference number of tools necessary for assembly / disassembly of the itemized parts.

Item	Tool designation	Reference N°	Assembly	Disassembly
3	Centering device	7079	X	X
5 / 17	Puller	0827		X
7	Pusher set	2351	X	
10 / 11 / 12	Pusher set	2363	X	
12	Pusher	1762	X	

Unlock (3).

Remove the ring (17).  
Use 2 threaded rods, diameter : **14 mm**, length : **400 mm**.  
Weld. Use a "MIG" process welding set.  
Use tool(s) **0827 + 2363**.

For the braking system portion see "MR : 50 619".

**Assembly**


Proceed in the reverse sequence to disassembly.  
Each hub must be fitted with bearings of the same make.


Position the hub (5), complete with bearings (6 / 9).  
Turn the hub and exert light pressure to guarantee installation.  
Check the toothed wheel (12) for buckle.  
Replace part (12) if  $A > 0.2 \text{ mm}$ .

Assemble the hub (5).  
Install the bearing (6).

Tighten the nut (3) in a preliminary stage at a torque of **500 Nm**, while turning the hub several times in both directions.  
Slacken the nut by about half a turn and bring the hub back onto the nut.  
Retighten the nut (3) at a torque of **250 Nm**, while turning the hub several times in both directions.  
Lock the nut (3)

Fill the hub with oil.





## AUSTERAS

### Removal

On vehicle or on support.  
Remove the roadwheels.  
Drain the oil from the hub.

### Disassembly

The item numbers indicated in the drawing on page **B4** correspond to the **sequence of disassembly**.

The table indicates the designation and the reference number of tools necessary for assembly / disassembly of the itemized parts.

Item	Tool designation	Reference N°	Assembly	Disassembly
3	Centering device	7079	X	X
5 / 17	Puller	0827		X
7	Pusher set	2351	X	
10 / 11 / 12	Pusher set	2363	X	
12	Pusher	1762	X	

Unlock (3).

Remove the ring (17).

Use **2** threaded rods, diameter : **14 mm**, length : **400 mm**.

Weld. Use a "MIG" process welding set.

Use tool(s) **0827 + 2363**.

For the braking system portion see "MR : 50 619".

## Assembly

Proceed in the reverse sequence to disassembly.

Each hub must be fitted with bearings of the same make.

Position the hub (5), complete with bearings (6 / 9).

Turn the hub and exert light pressure to guarantee installation.

Check the toothed wheel (12) for buckle.

Replace part (12) if **A > 0.2 mm**.

Assemble the hub (5).

Install the bearing (6).



Tighten the nut (3) in a preliminary stage at a torque of **500 Nm**, while turning the hub several times in both directions.

Slacken the nut by about half a turn and bring the hub back onto the nut.

Retighten the nut (3) at a torque of **250 Nm**, while turning the hub several times in both directions.



Lock the nut (3)

Fill the hub with oil.



**STUB AXLE**





44 0009A

**Removal**

On vehicle or on support.  
Remove the hub.  
(See chapter : **B**).

For the braking system portion see "MR : **50 619**".



**Disassembly**

The item numbers indicated in the drawing on page **C2** correspond to the **sequence of disassembly**.

**Assembly**

Proceed in the reverse sequence to disassembly.

Grease.



## Track rod

### Disassembly

On vehicle or on support.

The item numbers indicated in the drawing on page **C4** correspond to the **sequence of disassembly**.

### Assembly

Proceed in the reverse sequence to disassembly.

Assemble the plates (**5 / 6**).

Screw up the screws without tightening them.

Assemble the track rod (**3**).

Fit the actuator ram (**2**).

Tighten the screws (**a**) at the recommended torque.

Connect up the compressed air system and check for correct operation of the locking device.

## Adjustment

### The axle is adjusted on the vehicle.

Prior to adjustment, check the following:

- State and pressure of the tyres.
- State and height of the suspension.
- Vehicle unladen and in running order on flat ground, axle roadwheels on pivoting plates.

Install the front axle checking apparatus.

Lock the track rod.

Loosen nut (**b**) and clamp (**c**). Turn (**d**) to obtain the wheel alignment value (toe-in: **1.25** → **1.5 mm/m**).

Tighten clamp (**c**) to torque. Tighten nut (**b**) to torque.

Adjust the steering lock stop (**10**). Respect the dimension "**A = 32 mm**".

## TOOL

**RENAULT TRUCKS** divide tools into 3 categories

- **General-purpose tools** : Commercially available tools.
  - . **50 00 26 .... reference number** (possibility of purchasing through the RENAULT TRUCKS Spare Parts department).
  - . **4-figure reference number** (tools with RENAULT TRUCKS reference number, but available from the supplier).
- **Special tools** : Specially created tools, distributed by the RENAULT TRUCKS spare parts division.
- **Locally manufactured tools** : these tools are classified differently according to their degree of sophistication :
  - . **4-figure reference number** (represented by a drawing) : tools that are simple to make without need for special qualification.
  - . **50 00 26 .... reference number** (possibility of purchasing through the RENAULT TRUCKS Spare Parts department) : a certain skill is needed to make these tools.



**Three levels** (or echelons) determine their assignment

- **LEVEL 1** : Tools for servicing and minor tasks.
- **LEVEL 2** : Tools for major repairs.
- **LEVEL 3** : Tools for refurbishment.


General-purpose tools				
Ref. RENAULT TRUCKS	Description	Level	Quantity	Page
50 00 26 <b>0827</b>	Puller	1	1	B3
50 00 26 <b>2351</b>	Pusher set	1	1	B3
50 00 26 <b>2363</b>	Pusher set	1	1	B3

Locally manufactured tools				
Ref. RENAULT TRUCKS	Description	Level	Quantity	Page
<b>1762</b>	Pusher	2	1	B3
50 00 26 <b>7079</b>	Centering device	1	1	B3


Locally manufactured tools



FL 1762



- $\bigcirc \varnothing 16$  (x3)  $120^\circ$
  - $\oplus \varnothing 12$  (x7)
  - $\bullet \varnothing 14$  (x4)  $90^\circ$
  - $\bullet \varnothing 13$  (x3)  $120^\circ$
- $\sqrt{R6.5}$



FL 7079

